

```
/* Yeasu GS-232/G5400B Rotor Controller
Replaces Yeasu GS-232A
Written by Glen Popiel, KW5GP
```

This program is free software: you can redistribute it and/or modify it under the terms of the version 3 GNU General Public License as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <<http://www.gnu.org/licenses/>>.

```
*/
```

```
#define debug_mode 0 // Set to 1 for debug data on Serial Port

#include <Wire.h> // Include the I2C Communication Library
#include <EEPROM.h> // Include the EEPROM Library
#include "ADS1115.h" // Include the ADS1115.h Library (Library Updated to
fix errors)
#include "I2Cdev.h" // Include I2Cdev.h Library (Library Updated to fix
errors)

ADS1115 adc; // Define the ADS1115 as adc

#define rotate_up 3 // Define Rotate Up as Pin 3
#define rotate_down 2 // Define Rotate Down as Pin 2
#define rotate_left 4 // Define Rotate Left as Pin 4
#define rotate_right 5 // Define Rotate Right as Pin 5

#define BAUD_RATE 9600 // Set the Serial Port Baud rate to 9600

#define EEPROM_ID_BYTE 1 // EEPROM ID to validate EEPROM data location
#define EEPROM_ID 55 // EEPROM ID Value
#define EEPROM_AZ_CAL_0 2 // Azimuth Zero Calibration EEPROM location
#define EEPROM_AZ_CAL_MAX 4 // Azimuth Max Calibration Data EEPROM
location
#define EEPROM_EL_CAL_0 6 // Elevation Zero Calibration Data EEPROM
location
#define EEPROM_EL_CAL_MAX 8 // Elevation Max Calibration Data EEPROM
location

#define AZ_CAL_0_DEFAULT 0 // Preset the Azimuth Zero Calibration
Point to 0
#define AZ_CAL_MAX_DEFAULT 27000 // Preset the Azimuth Max
Calibration Point to 27000
#define EL_CAL_0_DEFAULT 0 // Preset the Elevation Zero
Calibration Point to 0
```

```

#define EL_CAL_MAX_DEFAULT 27000          // Preset the Elevation Max
Calibration Point to 27000

#define AZ_Tolerance 0  // Set the Azimuth Accuracy Tolerance
#define EL_Tolerance 0  // Set the Elevation Accuracy Tolerance

//variables
byte inByte = 0;  // incoming serial byte
byte serial_buffer[50];  // incoming serial byte buffer
int serial_buffer_index = 0;  // The index pointer variable for the
Serial buffer
int set_AZ;  // Azimuth set value
int set_EL;  // Elevation set value
int current_AZ;  // Current Azimuth raw value
int current_EL;  // Current Elevation raw value
String Serial_Send_Data;  // Data to send to Serial Port
int AZ_0;  // Azimuth Zero Value from EEPROM
int AZ_MAX;  // Azimuth Max Value from EEPROM
int EL_0;  // Elevation 0 Value from EEPROM
int EL_MAX;  //Elevation Max Value from EEPROM
int AZ_Degrees;  // mapped AZ ADC value to Degrees
int EL_Degrees;  // mapped EL ADC value to Degrees
String Requested_AZ;  // RS232 Requested Azimuth - M and short W command
String Requested_EL;  //RS232 Requested Azimuth and Elevation - Full W
command
int AZ_To;  // Requested AZ Move
int EL_To;  // Requested EL Move
int AZ_Distance;  // Distance to move AZ
int EL_Distance;  // Distance to move EL

void setup()
{
    pinMode(rotate_up, OUTPUT);  // Define the Control Pins as Outputs
    pinMode(rotate_down, OUTPUT);
    pinMode(rotate_left, OUTPUT);
    pinMode(rotate_right, OUTPUT);

    digitalWrite(rotate_up, LOW);  // Turn off all the Control Pins
    digitalWrite(rotate_down, LOW);
    digitalWrite(rotate_left, LOW);
    digitalWrite(rotate_right, LOW);

    Serial.begin(BAUD_RATE);  // initialize serial communication

    Wire.begin();  // join I2C bus

    adc.initialize();  // initialize ADS1115 16 bit A/D chip

    Wire.beginTransmission(0x48);  // Begin direct ADC communication
    Wire.write(0x1);  // Connect to adc and send two bytes - Set Config
Reg to all Ones
    Wire.write(0x7F);  // MSB
    Wire.write(0xFF);  // LSB
    Wire.endTransmission();  // End the direct ADC Communication

```

```

    adc.setMode(ADS1115_MODE_CONTINUOUS); // Set the ADC to free running
conversion mode
    adc.setGain(ADS1115_PGA_6P144); // set the ADC gain to 6.144 Volt
range, .0001875 Volts/step
    adc.setRate(ADS1115_RATE_475); // set ADC sample rate to 475 samples
per second
    adc.setMultiplexer(ADS1115_MUX_P0_NG); // Set the ADC to AN0+ Vs
ground Mode

    set_AZ = -1; // Preset the Azimuth and Elevation Move Variables
    set_EL = -1;

    read_eeprom_cal_data(); // Read the Azimuth and Elevation Calibration
Values from EEPROM

} // End Setup Loop

void loop()
{
    check_serial(); // Check the Serial Port for Data
    check_move(); // Check to see if executing move command
} // End Main Loop

// Functions

void read_eeprom_cal_data() // Function to Read the Azimuth and
Elevation Calibration Data
{
    if (EEPROM.read(EEPROM_ID_BYTE) == EEPROM_ID) // Verify the EEPROM has
valid data
    {
        if (debug_mode) // If in Debug Mode Print the Calibration Values
        {
            Serial.println("Read EEPROM Calibration Data Valid ID");
            Serial.println((EEPROM.read(EEPROM_AZ_CAL_0) * 256) +
EEPROM.read(EEPROM_AZ_CAL_0 + 1), DEC);
            Serial.println((EEPROM.read(EEPROM_AZ_CAL_MAX) * 256) +
EEPROM.read(EEPROM_AZ_CAL_MAX + 1), DEC);
            Serial.println((EEPROM.read(EEPROM_EL_CAL_0) * 256) +
EEPROM.read(EEPROM_EL_CAL_0 + 1), DEC);
            Serial.println((EEPROM.read(EEPROM_EL_CAL_MAX) * 256) +
EEPROM.read(EEPROM_EL_CAL_MAX + 1), DEC);
        }

        AZ_0 = (EEPROM.read(EEPROM_AZ_CAL_0)*256) +
EEPROM.read(EEPROM_AZ_CAL_0 + 1); // Read the Azimuth Zero Calibration
Value from EEPROM
        AZ_MAX = (EEPROM.read(EEPROM_AZ_CAL_MAX)*256) +
EEPROM.read(EEPROM_AZ_CAL_MAX + 1); // Read the Azimuth Maximum
Calibration Value from EEPROM
        EL_0 = (EEPROM.read(EEPROM_EL_CAL_0)*256) +
EEPROM.read(EEPROM_EL_CAL_0 + 1); // Read the Elevation Zero Calibration
Value from EEPROM

```

```

    EL_MAX = (EEPROM.read(EEPROM_EL_CAL_MAX)*256) +
EEPROM.read(EEPROM_EL_CAL_MAX + 1); // Read the Elevation Maximum
Calibration Value from EEPROM

    } else { // initialize eeprom to default values
    if (debug_mode)
    {
        Serial.println("Read EEPROM Calibration Data Invalid ID - setting to
defaults");
    }
    AZ_0 = AZ_CAL_0_DEFAULT; // Set the Calibration To Default Values
    AZ_MAX = AZ_CAL_MAX_DEFAULT;
    EL_0 = EL_CAL_0_DEFAULT;
    EL_MAX = EL_CAL_MAX_DEFAULT;
    write_eeprom_cal_data(); // Write the Default Values to EEPROM
    }
}

void write_eeprom_cal_data() // Function to Write the Calibration Values
to EEPROM
{
    if (debug_mode)
    {
        Serial.println("Writing EEPROM Calibration Data");
    }

    EEPROM.write(EEPROM_ID_BYTE,EEPROM_ID); // Write the EEPROM ID
    EEPROM.write(EEPROM_AZ_CAL_0,highByte(AZ_0)); // Write the Azimuth
Zero Calibration High Order Byte
    EEPROM.write(EEPROM_AZ_CAL_0 + 1,lowByte(AZ_0)); // Write the
Azimuth Zero Calibration Low Order Byte
    EEPROM.write(EEPROM_AZ_CAL_MAX,highByte(AZ_MAX)); // Write the Azimuth
Max Calibration High Order Byte
    EEPROM.write(EEPROM_AZ_CAL_MAX + 1,lowByte(AZ_MAX)); // Write the
Azimuth Max Calibration Low Order Byte
    EEPROM.write(EEPROM_EL_CAL_0,highByte(EL_0)); // Write the Elevation
Zero Calibration High Order Byte
    EEPROM.write(EEPROM_EL_CAL_0 + 1,lowByte(EL_0)); // Write the
Elevation Zero Calibration Low Order Byte
    EEPROM.write(EEPROM_EL_CAL_MAX,highByte(EL_MAX)); // Write the
Elevation Max Calibration High Order Byte
    EEPROM.write(EEPROM_EL_CAL_MAX + 1,lowByte(EL_MAX)); // Write the
Elevation Max Calibration Low Order Byte
}

void check_serial() // Function to check for data on the Serial port
{
    if (Serial.available() > 0) // Get the Serial Data if available
    {
        inByte = Serial.read(); // Get the Serial Data

        // You may need to comment out the following line if your PC software
        // will not communicate properly with the controller
        // SatPC32 wants the command echoed, Ham Radio Deluxe does not

```

```

Serial.print(char(inByte)); // Echo back to the PC

if (inByte == 10) // ignore Line Feeds
{
return;
}
if (inByte !=13) // Add to buffer if not CR
{
    serial_buffer[serial_buffer_index] = inByte;

    if (debug_mode) // Print the Character received if in Debug mode
    {
        Serial.print("Received = ");
        Serial.println(serial_buffer[serial_buffer_index]);
    }

    serial_buffer_index++; // Increment the Serial Buffer pointer
} else { // It's a Carriage Return, execute command

    if ((serial_buffer[0] > 96) && (serial_buffer[0] < 123)) //If first
character of command is lowercase, convert to uppercase
    {
        serial_buffer[0] = serial_buffer[0] - 32;
    }

    switch (serial_buffer[0]) { // Decode first character of command

        case 65: // A Command - Stop the Azimuth Rotation

            if (debug_mode) {Serial.println("A Command Received");}
            az_rotate_stop();
            break;

        case 66: // B Command - Send the Current Elevation to the PC

            if (debug_mode) {Serial.println("B Command Received");}
            send_current_el(); // Call the Send Current Elevation Function
            break;

        case 67: // C - return current azimuth

            if (debug_mode) // Return the Buffer Index Pointer in Debug
Mode
            {
                Serial.println("C Command Received");
                Serial.println(serial_buffer_index);
            }
            if ((serial_buffer_index == 2) & (serial_buffer[1] == 50))
            {
                if (debug_mode)
                {
                    Serial.println("C2 Command Received");
                }
            }
        }
    }
}

```

```

        send_current_azel(); // Return Azimuth and Elevation if C2
Command
    } else {
        send_current_az(); // Return Azimuth if C Command
    }
    break;

case 68: // D - Rotate Elevation Down Command

    if (debug_mode)
    {
        Serial.println("D Command Received");
    }
    rotate_el_down(); // Call the Rotate Elevation Down Function
    break;

case 69: // E - Stop the Elevation Rotation

    if (debug_mode)
    {
        Serial.println("E Command Received");
    }
    el_rotate_stop(); // Call the Elevation Rotation Stop Function
    break;

case 70: // F - Set the Max Calibration

    if (debug_mode)
    {
        Serial.println("F Command Received");
        Serial.println(serial_buffer_index);
    }
    if ((serial_buffer_index == 2) & (serial_buffer[1] == 50)) //
Check for F2 Command
    {
        if (debug_mode)
        {
            Serial.println("F2 Command Received");
        }
        set_max_el_cal(); // F2 - Set the Max Elevation Calibration
    } else {
        set_max_az_cal(); // F - Set the Max Azimuth Calibration
    }
    break;

case 76: // L - Rotate Azimuth CCW

    if (debug_mode)
    {
        Serial.println("L Command Received");
    }
    rotate_az_ccw(); // Call the Rotate Azimuth CCW Function
    break;

```

```

case 77: // M - Rotate to Set Point

    if (debug_mode)
    {
        Serial.println("M Command Received");
    }
    rotate_to(); // Call the Rotate to Set Point Command
    break;

case 79: // O - Set Zero Calibration

    if (debug_mode)
    {
        Serial.println("O Command Received");
        Serial.println(serial_buffer_index);
    }
    if ((serial_buffer_index == 2) & (serial_buffer[1] == 50)) //
Check for O2 Command
    {
        if (debug_mode)
        {
            Serial.println("O2 Command Received");
        }
        set_0_el_cal(); // O2 - Set the Elevation Zero Calibration
    } else {
        set_0_az_cal(); // O - Set the Azimuth Zero Calibration
    }
    break;

case 82: // R - Rotate Azimuth CW

    if (debug_mode)
    {
        Serial.println("R Command Received");
    }
    rotate_az_cw(); // Call the Rotate Azimuth CW Function
    break;

case 83: // S - Stop All Rotation

    if (debug_mode)
    {
        Serial.println("S Command Received");
    }
    az_rotate_stop(); // Call the Stop Azimuth Rotation Function
    el_rotate_stop(); // Call the Stop Elevation Rotation Function
    break;

case 85: // U - Rotate Elevation Up

    if (debug_mode)
    {
        Serial.println("U Command Received");
    }

```

```

        rotate_el_up(); // Call the Rotate Elevation Up Function
        break;

    case 87: // W - Rotate Azimuth and Elevation to Set Point

        if (debug_mode)
        {
            Serial.println("W Command Received");
        }
        rotate_az_el_to(); // Call the Rotate Azimuth and Elevation to
Set Point Function
        break;

    }

    serial_buffer_index = 0; // Clear the Serial Buffer and Reset the
Buffer Index Pointer
    serial_buffer[0] = 0;
}
}
}

void send_current_az() // Send the Current Azimuth Function
{
    read_adc(); // Read the ADC

    // Map Azimuth to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the Current
Azimuth to Degrees
    if (AZ_Degrees > 180) // Correction Since Azimuth Reading starts at
Meter Center Point
    {
        AZ_Degrees = AZ_Degrees - 180;
    } else {
        AZ_Degrees = AZ_Degrees + 180;
    }
    if (debug_mode)
    {
        Serial.println(AZ_Degrees);
    }
    // Send it back via serial
    Serial_Send_Data = "";
    if (AZ_Degrees < 100) // pad with 0's if needed
    {
        Serial_Send_Data = "0";
    }
    if (AZ_Degrees < 10)
    {
        Serial_Send_Data = "00";
    }
}

```



```

    Serial_Send_Data = "+0" + Serial_Send_Data + String(AZ_Degrees); //
Send the Azimuth in Degrees
    Serial.println(Serial_Send_Data); // Return value via RS-232 port
}

void send_current_azel() // Function to Send the Current Azimuth and
Elevation
{
    read_adc(); // Read the ADC

    // Map Azimuth to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the Current
Azimuth to Degrees
    if (AZ_Degrees > 180) // Correction Since Azimuth Reading starts at
Meter Center Point
    {
        AZ_Degrees = AZ_Degrees - 180;
    } else {
        AZ_Degrees = AZ_Degrees + 180;
    }

    // Map Elevation to degrees
    if (debug_mode)
    {
        Serial.println(current_EL);
    }
    EL_Degrees = map(current_EL, EL_0, EL_MAX, 0, 180); // Map the
Elevation to Degrees
    if (debug_mode)
    {
        Serial.println(EL_Degrees);
        Serial.println(AZ_Degrees);
    }
    // Send it back via serial
    Serial_Send_Data = "";
    if (AZ_Degrees < 100) // pad with 0's if needed
    {
        Serial_Send_Data = "0";
    }
    if (AZ_Degrees < 10)
    {
        Serial_Send_Data = "00";
    }
    Serial_Send_Data = "+0" + Serial_Send_Data + String(AZ_Degrees) + "+0";
    // Send the Azimuth part of the string
    if (EL_Degrees < 100) // pad with 0's if needed
    {
        Serial_Send_Data = Serial_Send_Data + "0";
    }
    if (EL_Degrees < 10)

```

```

    {
        Serial_Send_Data = Serial_Send_Data+ "0";
    }
    Serial_Send_Data = Serial_Send_Data + String(EL_Degrees); // Send the
Elevation Part of the String
    Serial.println(Serial_Send_Data); // Return value via RS-232 port
}

void set_max_az_cal() // Set the Max Azimuth Calibration Function
{
    if (debug_mode)
    {
        Serial.println("Calibrate Max AZ Function");
    }
    read_adc(); // Read the ADC

    // save current az and el values to EEPROM - Zero Calibration
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_MAX = current_AZ; // Set the Azimuth Maximum Calibration to Current
Azimuth Reading
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    if (debug_mode)
    {
        Serial.println("Max Azimuth Calibration Complete");
    }
}

void set_max_el_cal() // Set the Max Elevation Calibration Function
{
    if (debug_mode)
    {
        Serial.println("Calibrate EL Max Function");
    }
    read_adc(); // Read the ADC

    // save current Azimuth and Elevation values to EEPROM - Zero
Calibration
    if (debug_mode)
    {
        Serial.println(current_EL);
    }
    EL_MAX = current_EL; // Set the Elevation Max Calibration to the
Current Elevation Reading
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    if (debug_mode)
    {
        Serial.println("Max Elevation Calibration Complete");
    }
}

void rotate_az_ccw() // Function to Rotate Azimuth CCW

```

```

{
    digitalWrite(rotate_left, HIGH); // Set the Rotate Left Pin High
    digitalWrite(rotate_right, LOW); // Make sure the Rotate Right Pin is
Low
}

void rotate_az_cw() // Function to Rotate Azimuth CW
{
    digitalWrite(rotate_right, HIGH); // Set the Rotate Right Pin High
    digitalWrite(rotate_left, LOW); // Make sure the Rotate Left Pin Low
}

void rotate_el_up() // Function to Rotate Elevation Up
{
    digitalWrite(rotate_up, HIGH); // Set the Rotate Up Pin High
    digitalWrite(rotate_down, LOW); // Make sure the Rotate Down Pin is
Low
}

void rotate_el_down() // Function to Rotate Elevation Up
{
    digitalWrite(rotate_down, HIGH); // Set the Rotate Down Pin High
    digitalWrite(rotate_up, LOW); // Make sure the Rotate Up Pin is Low
}

void az_rotate_stop() // Function to Stop Azimuth Rotation
{
    digitalWrite(rotate_right, LOW); // Turn off the Rotate Right Pin
    digitalWrite(rotate_left, LOW); // Turn off the Rotate Left Pin
}

void el_rotate_stop() // Function to Stop Elevation Rotation
{
    digitalWrite(rotate_up, LOW); // Turn off the Rotate Up Pin
    digitalWrite(rotate_down, LOW); // Turn off the Rotate Down Pin
}

void rotate_to() // Function to Rotate to Set Point
{
    if (debug_mode)
    {
        Serial.println("M Command - Rotate Azimuth To Function");
    }
    // Decode Command - Format Mxxx - xxx = Degrees to Move to
    if (debug_mode)
    {
        Serial.println(serial_buffer_index);
    }
    if (serial_buffer_index == 4) // Verify the Command is the proper
length
    {
        if (debug_mode)
        {
            Serial.println("Value in [1] to [3]?");

```

```

    }
    Requested_AZ = (String(char(serial_buffer[1])) +
String(char(serial_buffer[2])) + String(char(serial_buffer[3]))) ; //
Decode the Azimuth Value
    AZ_To = (Requested_AZ.toInt()); // AZ Degrees to Move to as integer
    if (AZ_To < 0) // Make sure we don't go below 0 degrees
    {
        AZ_To = 0;
    }
    if (AZ_To > 360) // Make sure we don't go over 360 degrees
    {
        AZ_To = 360;
    }
    if (AZ_To > 180) // Adjust for Meter starting at Center
    {
        AZ_To = AZ_To - 180;
    } else {
        AZ_To = AZ_To + 180;
    }
    if (debug_mode)
    {
        Serial.println(Requested_AZ);
        Serial.println(AZ_To);
    }

    // set the move flag and start
    read_adc(); // Read the ADC

    // Map it to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the
Azimuth Value to Degrees
    if (debug_mode)
    {
        Serial.println(AZ_Degrees);
    }
    AZ_Distance = AZ_To - AZ_Degrees; // Figure out far we have to move
    set_AZ = AZ_To;
    if (abs(AZ_Distance) <= AZ_Tolerance) // No move needed if we're
within the Tolerance Range
    {
        az_rotate_stop(); // Stop the Azimuth Rotation
        set_AZ = -1; // Turn off the Move Command
    } else { // Move Azimuth - figure out which way
        if (AZ_Distance > 0) //We need to move CCW
        {
            rotate_az_ccw(); // If the distance is positive, move CCW
        } else {
            rotate_az_cw(); // Otherwise, move clockwise
        }
    }
}

```

```

    }
}

void send_current_el() // Function to Send the Current Elevation
{
    read_adc(); // Read the ADC
    // Map it to degrees
    if (debug_mode)
    {
        Serial.println(current_EL);
    }
    EL_Degrees = map(current_EL, EL_0, EL_MAX, 0, 180); // Map the
Elevation Value to Degrees
    if (debug_mode)
    {
        Serial.println(EL_Degrees);
        Serial.println(AZ_Degrees);
    }
    // Send it back via serial
    Serial_Send_Data = "";
    if (EL_Degrees < 100) // pad with 0's if needed
    {
        Serial_Send_Data = "0";
    }
    if (EL_Degrees < 10)
    {
        Serial_Send_Data = "00";
    }
    Serial_Send_Data = "+0" + Serial_Send_Data + String(EL_Degrees); //
Send the Elevation String
    Serial.println(Serial_Send_Data); // Return value via RS-232 port
}

void rotate_az_el_to() // Rotate Azimuth and Elevation to Set Point
Function
{
    if (debug_mode)
    {
        Serial.println("W Command - Rotate Azimuth and Elevation To
Function");
    }
    // Decode Command - Format Wxxx yyy where xxx = Azimuth to Move to yyy
= Elevation to Move to
    if (debug_mode)
    {
        Serial.println(serial_buffer_index);
    }
    if (serial_buffer_index == 8) // Verify the command is the proper
length
    {
        if (debug_mode)
        {
            Serial.println("Value in [1] to [3]?");
        }
    }
}

```

```

    Requested_AZ = (String(char(serial_buffer[1])) +
String(char(serial_buffer[2])) + String(char(serial_buffer[3]))) ; //
Decode the Azimuth portion of the command
    AZ_To = (Requested_AZ.toInt()); // AZ Degrees to Move to as integer
    if (AZ_To <0) // Don't allow moving below zero
    {
        AZ_To = 0;
    }
    if (AZ_To >360) // Don't allow moving above 360
    {
        AZ_To = 360;
    }
    if (AZ_To >180) // Adjust for Azimuth starting at Center
    {
        AZ_To = AZ_To - 180;
    } else {
        AZ_To = AZ_To + 180;
    }

    if (debug_mode)
    {
        Serial.println(Requested_AZ);
        Serial.println(AZ_To);
        Serial.println("Value in [5] to [7]?");
    }
    Requested_EL = (String(char(serial_buffer[5])) +
String(char(serial_buffer[6])) + String(char(serial_buffer[7]))) ; //
Decode the Elevation portion of the command
    EL_To = (Requested_EL.toInt()); // EL Degrees to Move to as integer
    if (EL_To <0) // Don't allow moving below zero
    {
        EL_To = 0;
    }
    if (EL_To >180) // Don't allow moving above 180
    {
        EL_To = 180;
    }
    if (debug_mode)
    {
        Serial.println(Requested_EL);
        Serial.println(EL_To);
    }

    // set the move flag and start
    read_adc(); // Read the ADC
    // Map it to degrees
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
    AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the
Azimuth Value to Degrees
    if (debug_mode)
    {

```

```

        Serial.println(AZ_Degrees);
    }
    AZ_Distance = AZ_To - AZ_Degrees; // Figure how far to move Azimuth
    set_AZ = AZ_To;
    EL_Degrees = map(current_EL, EL_0, EL_MAX, 0, 180); // Map the
Elevation Value to Degrees
    if (debug_mode)
    {
        Serial.println(EL_Degrees);
    }
    EL_Distance = EL_To - EL_Degrees; // Figure how far to move
Elevation
    set_EL = EL_To;
    // Set Azimuth
    if (abs(AZ_Distance) <= AZ_Tolerance) // No move needed if we're
within tolerance range
    {
        az_rotate_stop(); // Stop the Azimuth Rotation
        set_AZ = -1; // Turn off the Azimuth Move Command
    } else { // Move Azimuth - figure out which way
        if (AZ_Distance > 0) //We need to move CW
        {
            rotate_az_cw(); // Rotate CW if positive
        } else {
            rotate_az_ccw(); // Rotate CCW if negative
        }
    }
    // Set Elevation
    if (abs(EL_Distance) <= EL_Tolerance) // No move needed if we're
within tolerance range
    {
        el_rotate_stop(); // Stop the Elevation Rotation
        set_EL = -1; // Turn off the Elevation Move Command
    } else { // Move Elevation - figure out which way
        if (EL_Distance > 0) //We need to move CW
        {
            rotate_el_up(); // Rotate Up if positive
        } else {
            rotate_el_down(); // Rotate Down if negative
        }
    }
}
}

void set_0_az_cal() // Set Azimuth Zero Calibration
{
    if (debug_mode)
    {
        Serial.println("Calibrate Zero Function");
    }

    read_adc(); // Read the ADC
    // save current az and el values to EEPROM - Zero Calibration
    if (debug_mode)

```

```

    {
        Serial.println(current_EL);
        Serial.println(current_AZ);
    }
    AZ_0 = current_AZ; // Set the Azimuth Zero Calibration to current
position
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    if (debug_mode)
    {
        Serial.println("Zero Azimuth Calibration Complete");
    }
}

void set_0_el_cal() // Set the Elevation Zero Calibration
{
    if (debug_mode)
    {
        Serial.println("Calibrate Zero Function");
    }

    read_adc(); // Read the ADC
    // save current az and el values to EEPROM - Zero Calibration
    if (debug_mode)
    {
        Serial.println(current_EL);
        Serial.println(current_AZ);
    }
    EL_0 = current_EL; // Set the Elevation Zero Calibration to current
position
    write_eeprom_cal_data(); // Write the Calibration Data to EEPROM
    if (debug_mode)
    {
        Serial.println("Zero Elevation Calibration Complete");
    }
}

void read_adc() // Function to read the ADC
{
    if (debug_mode)
    {
        Serial.println("Read ADC Function ");
    }

    int RotorValue; // Variable to store the rotor value
    adc.setRate(ADS1115_RATE_475); // Set the ADC rate to 475 samples/sec
    adc.setGain(ADS1115_PGA_6P144); // Set the ADC gain to 6.144V
    adc.setMultiplexer(ADS1115_MUX_P0_NG); // Set the ADC to Channel 0
    AN0+ Vs ground
    delay(10); // adc settling delay
    current_EL = adc.getDiff0(); // Read ADC Channel 0
    if (debug_mode)
    {
        Serial.println(current_EL);
    }
}

```



```

    adc.setMultiplexer(ADS1115_MUX_P1_NG); // Set the ADC to Channel 1
    AN1+ Vs ground
    delay(10); // adc settling delay
    current_AZ = adc.getDiff1(); // Read ADC Channel 1
    if (debug_mode)
    {
        Serial.println(current_AZ);
    }
}

void check_move() // Check to see if we've been commanded to move
{
    if (set_AZ != -1 || set_EL != -1) { // We're moving - check and stop
as needed
        read_adc(); // Read the ADC
        // Map AZ to degrees
        if (debug_mode)
        {
            Serial.println(current_AZ);
        }
        AZ_Degrees = map(current_AZ, AZ_0, AZ_MAX, 0, 360); // Map the
Current Azimuth reading to Degrees
        // Map EL to degrees
        if (debug_mode)
        {
            Serial.println(current_EL);
        }
        EL_Degrees = map(current_EL, EL_0, EL_MAX, 0, 180); // Map the
Current Elevation to Degrees
        if (debug_mode)
        {
            Serial.println(EL_Degrees);
            Serial.println(AZ_Degrees);
        }

        if (set_AZ != -1) // If Azimuth is moving
        {
            AZ_Distance = set_AZ - AZ_Degrees; // Check how far we have to
move
            if (abs(AZ_Distance) <= AZ_Tolerance) // No move needed if we're
within the tolerance range
            {
                az_rotate_stop(); // Stop the Azimuth Rotation
                set_AZ = -1; // Turn off the Azimuth Move Command
            } else { // Move Azimuth - figure out which way
                if (AZ_Distance > 0) //We need to move CW
                {
                    rotate_az_cw(); // Rotate CW if positive
                } else {
                    rotate_az_ccw(); // Rotate CCW if negative
                }
            }
        }

        if (set_EL != -1) // If Elevation is moving

```

```

    {
        EL_Distance = set_EL - EL_Degrees; // Check how far we have to move
        if (abs(EL_Distance) <= EL_Tolerance) { // No move needed if we're
within tolerance range
            el_rotate_stop(); // Stop the Elevation Rotation
            set_EL = -1; // Turn off the Elevation Move Command
        } else { // Move Azimuth - figure out which way
            if (EL_Distance > 0) //We need to move CW
            {
                rotate_el_up(); // Rotate Up if positive
            } else {
                rotate_el_down(); // Rotate Down if negative
            }
        }
    }
}
}
}

```