

Q:

I'm about to hook up my R303-137 weather sat receiver. The computer audio input takes a stereo connection. Do I connect the receiver audio output to both sides, and, if not, to which side? Or can I just use a mono plug at both ends?

A:

The connection depends on the computer sound card and there are as many variations as there are sound cards. What I do is to use stereo plugs but only use the tip (audio) and ring (ground) connections (leave the middle conductor un-connected). This always works for me.